




# LMF 100/170 BOILER - Junction Box Detail



**General Notes**  
 1. Wirenuts 5, 6, 7 by installer.  
 2. Use crimp cap for Wirenut 4